


## 4. Exploded View and Parts List


### 4-1-1. Cellular phone Exploded View [SM-G998U/U1]



※ SVC REPAIR TAPE  
QRT01, QRT02

## 4. Exploded View and Parts List

### 4-1-2. Cellular phone Exploded View [SM-G998W]



## 4. Exploded View and Parts List

### 4-2-1. Cellular phone Parts list [SM-G988U]

Design LOC	Description	SEC CODE
QCR253	SCREW-MACHINE	6001-003427
QME03	UNIT-LEGACY FRC FPCB_SM-G998B	GH59-15421A
QMI02	MIC MEMS	3003-001258
QSP01	ASSY SPEAKER-SM-G998U	GH96-13978A
QCR254	SCREW-MACHINE	6001-003422
QCR252	SCREW-MACHINE	6001-003428
QAN02	ANTENNA-MMW,SM-G996U	GH42-06696A
QME05	CON TO CON FPCB-V2,SM-G996U	GH59-15398A
QME06	CON TO CON FPCB-V1,SM-G998U	GH59-15401A
QME04	CON TO CON FPCB-IF_SM-G998B	GH59-15418A
QIF01	ASSY SUB PBA-IF,SM-G998U	GH96-13949A
QCA03	ASSY VT CAMERA-1/2.8"_40M_SM-G998B	GH96-13974A
QMO01	MOTOR LINEAR VIBRATION	GH31-00786A
QME02	KEY FPCB-POWER,ASSY,SM-G998B	GH59-15426A
QCK01	ASSY KEY-PWR KEY_ZK	GH98-46221A
QBR01	ASSY BRACKET-VT CAM	GH98-46261A
QBR03	KEY-BRACKET POWER	GH64-08340A
QBR04	ASSY BRACKET-ASSY 5G ANT BRK OTP	GH98-46112A
QBR02	ASSY BRACKET-5G_N2	GH98-46113A
QCR252	SCREW-MACHINE	6001-003428
QCA05	ASSY CAMERA-1/2.55"_12M(G998B)	GH96-13968A
QCA04	ASSY CAMERA-10M CMOS_1/3"_G998B	GH96-13969A
QCA01	ASSY CAMERA-REAR_WIDE_SM-G998B	GH96-13980A
QCA02	ASSY CAMERA-10M 1/3"_G998U	GH96-13987A
QSM01	ASSY SIM TRAY-SS_ZK	GH98-46345A
QCR253	SCREW-MACHINE	6001-003427
QRE01	MEA REAR-TOP_USA	GH97-26024A
QME01	ASSY SUB PBA-RS FPCB_SM-G998B	GH96-14071A
QAN01	MEA ANTENNA-MID(OPEN)	GH97-26026A
QBC01	MEA BACK GLASS-USA_VZW/ATT_ZK	GH97-26065A
QMP01	SVC PBA-MAIN(SEA)SM-G998U/128GB,VZW	GH82-24593A
QBA01	SVC BATT ASSY-EB-BG998ABY,EUX,4855,30	GH82-24592A
QFR01	SVC LCD ASSY-OCTA KIT(E/ZK)SM-G998U,VZW	GH82-24594A
QFR01	SVC LCD ASSY-OCTA KIT(E/ZK/PF)G998U,VZW	GH82-24595A
QRT01	A/S REWORK KIT-SVC	GH82-24597A
QRT02	A/S REWORK KIT-SVC	GH82-24598A

## 4. Exploded View and Parts List

### 4-2-2. Cellular phone Parts list [SM-G988U1]

Design LOC	Description	SEC CODE
QCR253	SCREW-MACHINE	6001-003427
QCR252	SCREW-MACHINE	6001-003428
QME03	UNIT-LEGACY FRC FPCB_SM-G998B	GH59-15421A
QMI02	MIC MEMS	3003-001258
QCA05	ASSY CAMERA-1/2.55" _12M(G998B)	GH96-13968A
QCA04	ASSY CAMERA-10M CMOS_1/3" _G998B	GH96-13969A
QCA01	ASSY CAMERA-REAR_WIDE_SM-G998B	GH96-13980A
QCA02	ASSY CAMERA-10M 1/3" _G998U	GH96-13987A
QCR254	SCREW-MACHINE	6001-003422
QCR252	SCREW-MACHINE	6001-003428
QAN02	ANTENNA-MMW,SM-G996U	GH42-06696A
QME05	CON TO CON FPCB-V2,SM-G996U	GH59-15398A
QME06	CON TO CON FPCB-V1,SM-G998U	GH59-15401A
QME04	CON TO CON FPCB-IF_SM-G998B	GH59-15418A
QIF01	ASSY SUB PBA-IF,SM-G998U	GH96-13949A
QCA03	ASSY VT CAMERA-1/2.8" _40M_SM-G998B	GH96-13974A
QMO01	MOTOR LINEAR VIBRATION	GH31-00786A
QME02	KEY FPCB-POWER,ASSY,SM-G998B	GH59-15426A
QCK01	ASSY KEY-PWR KEY_ZK	GH98-46221A
QBR01	ASSY BRACKET-VT CAM	GH98-46261A
QBR03	KEY-BRACKET POWER	GH64-08340A
QBR04	ASSY BRACKET-ASSY 5G ANT BRK OTP	GH98-46112A
QBR02	ASSY BRACKET-5G_N2	GH98-46113A
QCR253	SCREW-MACHINE	6001-003427
QBC01	MEA BACK GLASS-USA_ZK	GH97-26012A
QSP01	ASSY SPEAKER-SM-G998U	GH96-13978A
QRE01	MEA REAR-TOP_USA	GH97-26024A
QME01	ASSY SUB PBA-RS FPCB_SM-G998B	GH96-14071A
QAN01	MEA ANTENNA-MID(OPEN)	GH97-26026A
QSM01	ASSY SIM TRAY-SS_ZK	GH98-46345A
QBA01	SVC BATT ASSY-EB-BG998ABY,EUX,4855,30	GH82-24592A
QMP01	SVC PBA-MAIN(SEA)SM-G998U/128GB,VZW	GH82-24593A
QFR01	SVC LCD ASSY-OCTA KIT(E/ZK)SM-G998U,VZW	GH82-24594A
QFR01	SVC LCD ASSY-OCTA KIT(E/ZK/PF)G998U,VZW	GH82-24595A
QRT01	A/S REWORK KIT-SVC	GH82-24597A
QRT02	A/S REWORK KIT-SVC	GH82-24598A

---

## 4. Exploded View and Parts List

---

### 4-2-3. Cellular phone Parts list [SM-G988W]

Design LOC	Description	SEC CODE
QCR253	SCREW-MACHINE	6001-003427
QCR252	SCREW-MACHINE	6001-003428
QME03	UNIT-LEGACY FRC FPCB_SM-G998B	GH59-15421A
QMI02	MIC MEMS	3003-001258
QCA05	ASSY CAMERA-1/2.55"_12M(G998B)	GH96-13968A
QCA04	ASSY CAMERA-10M CMOS_1/3"_G998B	GH96-13969A
QCA01	ASSY CAMERA-REAR_WIDE_SM-G998B	GH96-13980A
QCA02	ASSY CAMERA-10M 1/3"_G998U	GH96-13987A
QCR254	SCREW-MACHINE	6001-003422
QCR252	SCREW-MACHINE	6001-003428
QME04	CON TO CON FPCB-IF_SM-G998B	GH59-15418A
QIF01	ASSY SUB PBA-IF,SM-G998U	GH96-13949A
QCA03	ASSY VT CAMERA-1/2.8"_40M_SM-G998B	GH96-13974A
QMO01	MOTOR LINEAR VIBRATION	GH31-00786A
QME02	KEY FPCB-POWER,ASSY,SM-G998B	GH59-15426A
QCK01	ASSY KEY-PWR KEY_ZK	GH98-46221A
QBR01	ASSY BRACKET-VT CAM	GH98-46261A
QBR03	KEY-BRACKET POWER	GH64-08340A
QCR253	SCREW-MACHIN	6001-003427
QSP01	ASSY SPEAKER-SM-G998U	GH96-13978A
QRE01	MEA REAR-TOP_USA	GH97-26024A
QME01	ASSY SUB PBA-RS FPCB_SM-G998B	GH96-14071A
QAN01	MEA ANTENNA-MID(OPEN)	GH97-26026A
QSM01	ASSY SIM TRAY-SS_ZK	GH98-46345A
QBC01	SVC COVER ASSY-B/G_USA COMM_ZK_VN	GH82-24497A
QBA01	SVC BATT ASSY-EB-BG998ABY,EUX,4855,30	GH82-24592A
QFR01	SVC LCD ASSY-OCTA KIT(E/ZK/PF)G998U,VZW	GH82-24595A
QMP01	SVC PBA-MAIN(CNDA)SM-G998W_128GB,XAC	GH82-24675A
QRT01	A/S REWORK KIT-SVC	GH82-24597A